

# STUD BOY APPLICATION CHART YAMAHA 2000

Riding Style									
Snowmobile Information			Safety		Performance		Wearbars		
2000 Model	Lug Height	Track Length	Stud Length	Stud Quantity	Stud Length	Stud Quantity	Deuce	Round	Shaper
Mountain Max 600	2.000	15x141	Na	Na	NA	NA	NA	YAM-R2204-(add size)	YAM-S2204-(add size)
Mountain Max 700	2.000	15x141	Na	Na	NA	NA	NA	YAM-R2204-(add size)	YAM-S2204-(add size)
Phazer Mountain Lite	1.500	15x136	Na	Na	NA	NA	NA	YAM-R2204-(add size)	YAM-S2204-(add size)
Phazer 500	0.750	15x121	0.875	72/96	0.875	96/120	NA	YAM-2197-(add size)	NA
SRX 700	0.920	15x121	1.000	144	1.080	168/192	NA	YAM-R2204-(add size)	YAM-S2204-(add size)
Venture 500	0.750	15x136	0.875	81	0.875	108	NA	YAM-R2141-(add size)	NA
Venture 600	0.750	15x136	0.875	108	0.875	135	NA	YAM-R2141-(add size)	NA
Venture 700	0.750	15x136	0.875	135	0.875	162	NA	YAM-R2141-(add size)	NA
Venture XL	0.750	15x136	0.875	81	0.875	108	NA	YAM-R2197-(add size)	NA
VK540 II	1.000	20x156	1.000	93	1.000	96	NA	YAM-2082-(add size)	NA
SX 500 R	0.920	15x121	1.000	96/120	1.080	144	NA	YAM-R2204-(add size)	YAM-S2204-(add size)
VMAX 500 / DLX	0.920	15x121	1.000	96	1.080	120/144	NA	YAM-R2141-(add size)	NA
SX 600 R	0.920	15x121	1.000	120	1.080	144	NA	YAM-R2204-(add size)	NA
VMAX 600 DLX	0.920	15x121	1.000	96/120	1.080	144	NA	YAM-R2141-(add size)	NA
SX 700 R	0.920	15x121	1.000	120/144	1.080	168/192	NA	YAM-R2204-(add size)	NA
VMAX 700 / DLX	0.920	15x121	1.000	120/144	1.000	168/192	NA	YAM-R2141-(add size)	NA

\*121" Tracks Have 48 Lugs /128" Tracks Have 51 Lugs/ 136" Tracks Have 54 Lugs / 141" Tracks Have 47 Lugs/144" Tracks Have 57 Lugs /156" Tracks Have 62 Lugs

**\*\* PLEASE REMEMBER THAT "DEUCE" BARS ARE SOLD AS SINGLE BARS – NOT AS A PAIR**

Liberty Products, Inc. recommends that tunnel and/or heat exchanger protection be installed in all snowmobiles when traction products are utilized. Even if your snowmobile is equipped with factory tunnel protection we suggest that you check for adequate clearance of traction products before you ride. Riding without performing a clearance check can result in serious damage to your snowmobile. Stud quantity and carbide length must be balanced for safe and proper handling. If you are not using studs do not install overly aggressive wearbars.