

# STUD BOY APPLICATION CHART

## ARCTIC CAT 2003

Snowmobile Information			Riding Style				Wearbars		
			Safety		Performance				
2003 Model	Lug Height	Track Length	Stud Length	Stud Quantity	Stud Length	Stud Quantity	Deuce	Round	Shaper
4-STROKE TOURING	1.000	15x136	1.080	108	1.080	135	CAT-D2093-(add size)	CAT-R2093-(add size)	CAT-S2093-(add size)
4-STROKE TRAIL	1.000	15x121	1.080	96	1.080	120/144	CAT-D2093-(add size)	CAT-R2093-(add size)	CAT-S2093-(add size)
Bearcat WT	1.000	20x156	1.080	93	1.080	124	CAT-D2093-(add size)	CAT-R2093-(add size)	CAT-S2093-(add size)
F7/F5 Firecat	1.000	13.5x128	1.080	102 (F5)	1.080	127 (F5)	CAT-D2264-(add size)	CAT-R2264-(add size)	CAT-S2264-(add size)
				127 (F7)		153 (F7)	CAT-D2264-(add size)	CAT-R2264-(add size)	CAT-S2264-(add size)
F7/F5 Firecat Sno-Pro	1.375	13.5x128	1.500	102 (F5)	1.500	127 (F5)	CAT-D2264-(add size)	CAT-R2264-(add size)	CAT-S2264-(add size)
				127 (F7)		153 (F7)	CAT-D2264-(add size)	CAT-R2264-(add size)	CAT-S2264-(add size)
Pantera 550	1.000	15x136	1.080	108	1.080	135	CAT-D2093-(add size)	CAT-R2093-(add size)	CAT-S2093-(add size)
Pantera 600/800EFI	1.000	15x136	1.080	108	1.080	135	CAT-D2093-(add size)	CAT-R2093-(add size)	CAT-S2093-(add size)
Panther 570 ESR	1.000	15x136	1.080	108	1.080	135	CAT-D2093-(add size)	CAT-R2093-(add size)	CAT-S2093-(add size)
Mountian Cat 570	1.400	15x136	1.625	108	1.625	135	CAT-D2093-(add size)	CAT-R2093-(add size)	CAT-S2093-(add size)
Mountian Cat 600/EFI	2.000	15x136	NA	NA	NA	NA	CAT-D2093-(add size)	CAT-R2093-(add size)	CAT-S2093-(add size)
Mountain Cat 900/800EFI	2.000	15x144	NA	NA	NA	NA	CAT-D2093-(add size)	CAT-R2093-(add size)	CAT-S2093-(add size)
Z 370 / ES	0.750	15x121	0.875	72/96	0.960	96/120	NA	CAM-R2395-(add size)	CAM-S2395-(add size)
Z 440 / ESR	0.750	15x121	0.875	96	0.960	120	NA	CAM-R2395-(add size)	CAM-S2395-(add size)
Z 570 / ESR	0.850	15x121	1.000	96/120	1.080	120/144	NA	CAM-R2395-(add size)	CAM-S2395-(add size)
ZL 550 / ESR	1.000	15x121	1.080	96/120	1.080	120/144	CAT-D2093-(add size)	CAT-R2093-(add size)	CAT-S2093-(add size)
ZL 600 / EFI / ESR / SS	1.000	15x121	1.080	120/144	1.080	168/192	CAT-D2093-(add size)	CAT-R2093-(add size)	CAT-S2093-(add size)
ZL 800/ EFI / ESR / SS	1.000	15x121	1.080	144/168	1.080	192/240	CAT-D2093-(add size)	CAT-R2093-(add size)	CAT-S2093-(add size)
ZR 120	0.500	11X68	TBA	TBA	TBA	TBA	NA	CAT-R2217-(add size)	NA
ZR 900/ 800 EFI	1.000	15x121	1.080	144/168	1.187	192/240	CAT-D2264-(add size)	CAT-R2264-(add size)	CAT-S2264-(add size)
ZR 900/800EFI Sno-Pro	1.250	15x121	1.375	144/168	1.375	192	CAT-D2264-(add size)	CAT-R2264-(add size)	CAT-S2264-(add size)

\*121" Tracks Have 48 Lugs /128" Tracks Have 51 Lugs/ 136" Tracks Have 54 Lugs / 141" Tracks Have 47 Lugs/144" Tracks Have 57 Lugs /156" Tracks Have 62 Lugs

**\*\* PLEASE REMEMBER THAT "DEUCE" BARS ARE SOLD AS SINGLE BARS – NOT AS A PAIR**

Liberty Products, Inc. recommends that tunnel and/or heat exchanger protection be installed in all snowmobiles when traction products are utilized. Even if your snowmobile is equipped with factory tunnel protection we suggest that you check for adequate clearance of traction products before you ride. Riding without performing a clearance check can result in serious damage to your snowmobile. Stud quantity and carbide length must be balanced for safe and proper handling. If you are not using studs do not install overly aggressive wearbars.