

STUD BOY APPLICATION CHART

POLARIS 2004

Snowmobile Information			Riding Style				Wearbars		
			Safety		Performance				
2004 Model	Lug Height	Track Length	Stud Length	Stud Quantity	Stud Length	Stud Quantity	Deuce	Round	Shaper
Trail Touring	1.000	15X136	1.080	108	1.080	162	POL-D1225-(add size)	POL-R1225-(add size)	POL-S1225-(add size)
Sport Touring	1.000	15x136	1.080	81	1.080	108/135	POL-D1225-(add size)	POL-R1225-(add size)	POL-S1225-(add size)
Trail RMK 136"	1.250	15x136	1.375	81	1.375	108	POL-D1225-(add size)	POL-R1225-(add size)	POL-S1225-(add size)
Super Sport	0.820	15x121	0.875	72/96	1.000	120/144	POL-D1225-(add size)	POL-R1225-(add size)	POL-S1225-(add size)
WideTrak LX	1.000	20x156	1.080	93	1.080	124	POL-D1225-(add size)	POL-R1225-(add size)	POL-S1225-(add size)
Frontier Touring	1.000	15x136	1.080	81	1.080	108/135	POL-D1225-(add size)	POL-R1225-(add size)	POL-S1225-(add size)
Frontier Classic	1.000	15x121	1.080	96/120	1.080	144/168	POL-D1225-(add size)	POL-R1225-(add size)	POL-S1225-(add size)
500 Indy	0.820	15x121	0.960	96	1.000	120/144	POL-D1225-(add size)	POL-R1225-(add size)	POL-S1225-(add size)
120 Pro X	0.790	10x69	N/A	N/A	N/A	N/A	NA	POL-R2219-(add size)	NA
340 Classic	0.820	15x121	0.875	72	0.875	96/120	POL-D1225-(add size)	POL-R1225-(add size)	POL-S1225-(add size)
340 Indy	0.820	15x121	0.875	72	1.000	96/120	POL-D1225-(add size)	POL-R1225-(add size)	POL-S1225-(add size)
340 Touring	1.000	15x136	1.080	80	1.080	106	POL-D1225-(add size)	POL-R1225-(add size)	POL-S1225-(add size)
500 XC SP	0.910	15x121	1.000	96	1.080	120/144	POL-D1225-(add size)	POL-R1225-(add size)	POL-S1225-(add size)
500Classic	1.000	15x121	1.080	96	1.080	120/144	POL-D1225-(add size)	POL-R1225-(add size)	POL-S1225-(add size)
550 Classic/ProX	0.820	15x121	0.875	96	0.875	144	POL-D1225-(add size)	POL-R1225-(add size)	POL-S1225-(add size)
600 EdgeTouring	1.000	15x136	1.080	108	1.080	162	POL-D1225-(add size)	POL-R1225-(add size)	POL-S1225-(add size)
600 XC SP	0.910	15x121	1.000	120	1.080	144/168	POL-D1225-(add size)	POL-R1225-(add size)	POL-S1225-(add size)
600 Pro X	1.000	15x121	1.080	120	1.187	144/168	POL-D1225-(add size)	POL-R1225-(add size)	POL-S1225-(add size)
600 Pro X2	1.250	15x121	1.375	96	1.375	144	POL-D1225-(add size)	POL-R1225-(add size)	POL-S1225-(add size)
600 Classic	1.000	15x121	1.080	96/120	1.080	144/168	POL-D1225-(add size)	POL-R1225-(add size)	POL-S1225-(add size)
600 RMK	2.000	15x144	N/A	N/A	N/A	N/A	NA	NA	NA
600 Switchback	1.250	15x144	1.375	114	1.375	171	NA	NA	NA
700XC SP/Pro X	1.000	15x121	1.080	144	1.187	168/192	POL-D1225-(add size)	POL-R1225-(add size)	POL-S1225-(add size)
700 EdgeTouring	1.000	15x136	1.080	108	1.080	162	POL-D1225-(add size)	POL-R1225-(add size)	POL-S1225-(add size)
700 Pro X2	1.250	15x121	1.375	120	1.375	168	POL-D1225-(add size)	POL-R1225-(add size)	POL-S1225-(add size)
700 Classic	1.000	15x121	1.080	120/144	1.080	144/168	POL-D1225-(add size)	POL-R1225-(add size)	POL-S1225-(add size)
700 RMK	2.000	15x144/151	N/A	N/A	N/A	N/A	NA	NA	NA
700 Switchback	1.250	15x144	1.375	114	1.375	171	NA	NA	NA
800 Classic	1.000	15x121	1.080	120/144	1.080	144/168	POL-D1225-(add size)	POL-R1225-(add size)	POL-S1225-(add size)
800 EdgeTouring	1.000	15x136	1.080	108	1.080	162	POL-D1225-(add size)	POL-R1225-(add size)	POL-S1225-(add size)
800XC SP/Pro X	1.000	15x121	1.080	144/168	1.187	192/240	POL-D1225-(add size)	POL-R1225-(add size)	POL-S1225-(add size)
800 Pro X2	1.250	15x121	1.375	144	1.375	192	POL-D1225-(add size)	POL-R1225-(add size)	POL-S1225-(add size)
800 RMK 144"/151"/159"	2.000	15x144/151/159	N/A	N/A	N/A	N/A	NA	NA	NA
800 Switchback	1.250	15x144	1.375	114	1.375	171/228	NA	NA	NA
800 Pro XR	1.375	14x121	1.500	144/168	1.500	192/240	POL-D1225-(add size)	POL-R1225-(add size)	POL-S1225-(add size)

*121" Tracks Have 48 Lugs /128" Tracks Have 51 Lugs/ 136" Tracks Have 54 Lugs / 141" Tracks Have 47 Lugs/144" Tracks Have 57 Lugs /156" Tracks Have 62 Lugs

**** PLEASE REMEMBER THAT "DEUCE" BARS ARE SOLD AS SINGLE BARS – NOT AS A PAIR**

Liberty Products, Inc. recommends that tunnel and/or heat exchanger protection be installed in all snowmobiles when traction products are utilized. Even if your snowmobile is equipped with factory tunnel protection we suggest that you check for adequate clearance of traction products before you ride. Riding without performing a clearance check can result in serious damage to your snowmobile. Stud quantity and carbide length must be balanced for safe and proper handling. If you are not using studs do not install overly aggressive wearbars.