

# STUD BOY APPLICATION CHART

## SKI DOO 2008

Snowmobile Information			Riding Style				Wearbars		
			Safety		Performance				
2008 Model	Lug Height	Track Length	Stud Length	Stud Quantity	Stud Length	Stud Quantity	Deuce	Round	Shaper
Freestyle Session 300	0.720	15 x 121	0.875	72	.875	96	NA	CAM-R2395-(add size)	CAM-S2395-(add size)
Freestyle Back Country	1.250	16 x 136	1.375	108	1.375	135	NA	CAM-R2395-(add size)	CAM-S2395-(add size)
Freestyle Park	1.250	15 x 121	1.375	96	1.375	120	NA	CAM-R2395-(add size)	CAM-S2395-(add size)
MX-Z Fan	0.880	15 x 121	1.000	96	1.000	120	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
MXZ Trail 500	1.000	15 x 120	1.080	84	1.080	126	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
MXZ 550 X	1.250	15 x 121	1.375	96	1.375	144	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
MXZ Adrenaline	1.000	15 x 120	1.080	84	1.080	126	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
600 HO SDI									
800R Power TEK	1.000	15 x 120	1.080	126	1.080	168			
MXZ TNT	1.000	15 x 120	1.080	84	1.080	126	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
MXZ Renegade/X 600 HO SDI	1.250	16 x 137	1.375	96	1.375	144	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
800R Power TEK									
<b>+ X models</b>				144		192			
MXZ X 600 HO SDI	1.250	15 x 120	1.375	84	1.375	126	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
MXZ X 800 Power TEK				126		168	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
Mach Z Adrenaline	1.000	15 x 121	1.080	144	1.187	192	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
Mach Z LT	1.250	15 x 136	1.375	162	1.375	216	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
Mach Z X	1.250	15 x 121	1.375	144	1.375	192	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
Summit Adrenaline	2.250	16 x 144	N/A	N/A	N/A	N/A	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
Summit Highmark X	2.250	16 x 162	N/A	N/A	N/A	N/A	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
Summit X (all) / Everest (all)	2.250	16 x ALL	N/A	N/A	N/A	N/A	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
Summit Fan	1.750	16 x 136	1.875	108	1.875	162	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
GSX Sport	1.000	15 x 120	1.080	84	1.080	126	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
GSX Limited 600/Touring	1.000	15 x 120	1.080	84	1.080	126	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
GSX Limited 800				126		168	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
GSX Fan	.880	15 x 121	1.000	96	1.000	120	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
GTX Fan	1.250	16 x 136	1.375	108	1.375	162	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
GTX Sport 500/600 HO	.880	15 x 136	1.000	108	1.000	162	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
GTX Limited	.880	15 x 136	1.000	108	1.000	162	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
Skandic Tundra	1.250	16 x 136	1.375	108	1.375	108	NA	CAM-R2395-(add size)	CAM-S2395-(add size)
Skandic Tundra LT	1.500	16 x 154	1.625	108	1.625	162	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
Skandic WT / SUV	1.250	20 x 156	1.375	93	1.375	124	NA	NA	NA
Skandic SWT 550 Fan	1.250	24 x 156	1.375	93	1.375	124	NA	NA	NA
Skandic SWT 4 Stroke	1.250	24 x 156	1.375	93	1.375	124	NA	NA	NA
Legend Trail	.880	15 x 121	1.000	96	1.000	120	NA	CAM-R2395-(add size)	CAM-S2395-(add size)
Legend Touring	.880	15 x 136	1.000	108	1.000	135	NA	CAM-R2395-(add size)	CAM-S2395-(add size)
Expedition Sport	1.250	16 x 136	1.375	108	1.375	162	NA	NA	NA
Expedition TUV	1.250	20 x 156	1.375	93	1.375	124	NA	NA	NA

\*121" Tracks Have 48 Lugs /128" Tracks Have 51 Lugs/ 136" Tracks Have 54 Lugs / 141" Tracks Have 47 Lugs/144" Tracks Have 57 Lugs /156" Tracks Have 62 Lugs

**\*\* PLEASE REMEMBER THAT "DUCE" BARS ARE SOLD AS SINGLE BARS - NOT AS A PAIR**

Liberty Products, Inc. recommends that tunnel and/or heat exchanger protection be installed in all snowmobiles when traction products are utilized. Even if your snowmobile is equipped with factory tunnel protection we suggest that you check for adequate clearance of traction products before you ride. Riding without performing a clearance check can result in serious damage to your snowmobile. Stud quantity and carbide length must be balanced for safe and proper handling. If you are not using studs do not install overly aggressive wearbars.

**CK AND STUD INFORMATION IN BOLD REPRESENT SINGLE PLY TRACKS WHICH REQUIRE POWER POINT PLUS STUD**