

# STUD BOY APPLICATION CHART

## POLARIS 2008

Snowmobile Information			Riding Style				Wearbars		
			Safety		Performance				
2008 Model	Lug Height	Track Length	Stud Length	Stud Quantity	Stud Length	Stud Quantity	Deuce	Round	Shaper
Trail Touring	1.000	15 x 136	1.080	108	1.080	108	NA	CAM-R2395-(add size)	CAM-S2395-(add size)
340 Transport	1.250	15 x 136	1.375	108	1.375	108	NA	CAM-R2395-(add size)	CAM-S2395-(add size)
Trail RMK	1.250	15 x 136	1.375	108	1.375	108	POL-D2370-(add size)	POL-R2370-(add size)	POL-S2370-(add size)
WideTrak LX	1.000	20 x 156	1.080	93	1.080	124	NA	NA	NA
Dragon IQ (ALL)	1.250	15 x 121	1.375	144	1.375	192	POL-D2370-(add size)	POL-R2370-(add size)	POL-S2370-(add size)
120	0.790	10 x 69	N/A	N/A	N/A	N/A	NA	POL-R2219-(add size)	NA
340	0.820	15 x 121	0.875	72	0.875	96	NA	CAM-R2395-(add size)	CAM-S2395-(add size)
550 LX	0.820	15 x 121	0.875	96	0.875	120	NA	CAM-R2395-(add size)	CAM-S2395-(add size)
IQ Shift	0.910	15 x 121	1.000	144	1.000	192	POL-D2370-(add size)	POL-R2370-(add size)	POL-S2370-(add size)
SuperSport	0.820	15 x 121	0.875	96	0.875	96	NA	CAM-R2395-(add size)	CAM-S2395-(add size)
IQ Turbo LX	1.000	15 x 128	1.080	102	1.080	153	POL-D2370-(add size)	POL-R2370-(add size)	POL-S2370-(add size)
600 IQ LX	1.000	15 x 128	1.080	102	1.080	153	POL-D2370-(add size)	POL-R2370-(add size)	POL-S2370-(add size)
600RR	1.250	15 x 121	1.375	144	1.375	192	NA	NA	POL-S2373-(add size)
Dragon Switchback	1.250	15 x 136	1.375	162	1.375	216	POL-D2370-(add size)	POL-R2370-(add size)	POL-S2370-(add size)
700 IQ	1.000	15 x 121	1.080	144	1.080	192	POL-D2370-(add size)	POL-R2370-(add size)	POL-S2370-(add size)
IQ Cruiser	1.000	15 x 136	1.080	108	1.080	162	POL-D2370-(add size)	POL-R2370-(add size)	POL-S2370-(add size)
Switchback (ALL)	1.250	15 x 136	1.375	162	1.375	189	POL-D2370-(add size)	POL-R2370-(add size)	POL-S2370-(add size)
FS IQ Touring	1.000	15 x 136	1.080	108	1.080	162	POL-D2370-(add size)	POL-R2370-(add size)	POL-S2370-(add size)
FST IQ Touring	1.000	15 x 136	1.080	108	1.080	162	POL-D2370-(add size)	POL-R2370-(add size)	POL-S2370-(add size)
600 IQ Touring	1.000	15 x 136	1.080	108	1.080	162	POL-D2370-(add size)	POL-R2370-(add size)	POL-S2370-(add size)
700 Dragon 155/163	2.400	15 x 163	N/A	N/A	N/A	N/A	NA	NA	POL-S2484-(add size)
600/700 RMK 155	2.400	15 x 155	N/A	N/A	N/A	N/A	NA	NA	POL-S2484-(add size)
600 RMK 144	2.000	15 x 144	N/A	N/A	N/A	N/A	NA	NA	POL-S2484-(add size)
800 Dragon 155/163	2.400	15 x 163	N/A	N/A	N/A	N/A	POL-D2370-(add size)	POL-R2370-(add size)	POL-S2370-(add size)

\*121" Tracks Have 48 Lugs /128" Tracks Have 51 Lugs/ 136" Tracks Have 54 Lugs / 141" Tracks Have 47 Lugs/144" Tracks Have 57 Lugs /156" Tracks Have 62 Lugs

**\*\* PLEASE REMEMBER THAT "DEUCE" BARS ARE SOLD AS SINGLE BARS – NOT AS A PAIR**

Liberty Products, Inc. recommends that tunnel and/or heat exchanger protection be installed in all snowmobiles when traction products are utilized.

Even if your snowmobile is equipped with factory tunnel protection we suggest that you check for adequate clearance of traction products before you

ride. Riding without performing a clearance check can result in serious damage to your snowmobile. Stud quantity and carbide length must be balanced

for safe and proper handling. If you are not using studs do not install overly aggressive wearbars.