

STUD BOY APPLICATION CHART

ARCTIC CAT 2009

Snowmobile Information			Riding Style				Wearbars		
			Safety		Performance				
2009 Model	Lug Height	Track Length	Stud Length	Stud Quantity	Stud Length	Stud Quantity	Deuce	Round	Shaper
Bearcat 570 XT	1.000	20 x 156	1.080	93	1.080	124	CAT-D2264-(add size)	CAT-R2264-(add size)	CAT-S2264-(add size)
Bearcat Z1 XT	1.250	20 x 156	1.375	124	1.375	155	CAT-D2264-(add size)	CAT-R2264-(add size)	CAT-S2264-(add size)
Bearcat 570	1.250	15 x 144	1.375	114	1.375	142	CAT-D2264-(add size)	CAT-R2264-(add size)	CAT-S2264-(add size)
Crossfire 5/6	1.250	15 x 141	1.375	142	1.375	188	CAT-D2264-(add size)	CAT-R2264-(add size)	CAT-S2264-(add size)
Crossfire 8/1000	1.250	15 x 141	1.375	165	1.375	188	CAT-D2264-(add size)	CAT-R2264-(add size)	CAT-S2264-(add size)
Crossfire 8/1000SnoPro	1.500	15 x 141	1.625	165	1.625	188	CAT-D2264-(add size)	CAT-R2264-(add size)	CAT-S2264-(add size)
Crossfire R 8/1000	1.000	14 x 128	1.080	153	1.080	170	CAT-D2264-(add size)	CAT-R2264-(add size)	CAT-S2264-(add size)
F5 & LXR	1.000	15 x 128	1.080	136	1.187	153/170	CAT-D2264-(add size)	CAT-R2264-(add size)	CAT-S2264-(add size)
F6 Sno Pro	1.250	15 x 128	1.375	136	1.375	153/170	CAT-D2264-(add size)	CAT-R2264-(add size)	CAT-S2264-(add size)
F8/F8LXR	1.000	15 x 128	1.080	153	1.187	170	CAT-D2264-(add size)	CAT-R2264-(add size)	CAT-S2264-(add size)
F8/F1000 Sno-Pros	1.250	15 x 128	1.375	153	1.375	170	CAT-D2264-(add size)	CAT-R2264-(add size)	CAT-S2264-(add size)
Z1/Z1 LXR	1.000	15 x 128	1.080	153	1.187	170	CAT-D2264-(add size)	CAT-R2264-(add size)	CAT-S2264-(add size)
T Z1/TZ1 LXR/TZ1 Turbo Touring LXR	1.000	15 x 144	1.080	114	1.080	170	CAT-D2264-(add size)	CAT-R2264-(add size)	CAT-S2264-(add size)
M6	2.250	15 x 153	N/A	N/A	N/A	N/A	CAT-D2264-(add size)	CAT-R2264-(add size)	CAT-S2264-(add size)
M8/Sno Pro 153-162	2.250	15 x 162	N/A	N/A	N/A	N/A	CAT-D2264-(add size)	CAT-R2264-(add size)	CAT-S2264-(add size)
M1000/SnoPro 153/162	2.250	15 x 162	N/A	N/A	N/A	N/A	CAT-D2264-(add size)	CAT-R2264-(add size)	CAT-S2264-(add size)
T500	1.000	15 x 144	1.080	114	1.080	170	CAT-D2264-(add size)	CAT-R2264-(add size)	CAT-S2264-(add size)
T570	1.000	15 x 144	1.080	114	1.080	170	CAT-D2264-(add size)	CAT-R2264-(add size)	CAT-S2264-(add size)
Z1 Turbo	1.000	15 x 128	1.080	136	1.080	153/170	CAT-D2264-(add size)	CAT-R2264-(add size)	CAT-S2264-(add size)
Z1 Turbo LXR	1.250	15 x 128	1.375	136	1.375	153/170	CAT-D2264-(add size)	CAT-R2264-(add size)	CAT-S2264-(add size)
F570	1.000	15 x 128	1.080	102	1.080	136	CAT-D2264-(add size)	CAT-R2264-(add size)	CAT-S2264-(add size)
120	0.500	10 X 68	N/A	N/A	N/A	N/A	NA	CAT-R2217-(add size)	NA

*121" Tracks Have 48 Lugs /128" Tracks Have 51 Lugs/ 136" Tracks Have 54 Lugs / 141" Tracks Have 47 Lugs/144" Tracks Have 57 Lugs /156" Tracks Have 62 Lugs

**** PLEASE REMEMBER THAT "DEUCE" BARS ARE SOLD AS SINGLE BARS – NOT AS A PAIR**

Liberty Products, Inc. recommends that tunnel and/or heat exchanger protection be installed in all snowmobiles when traction products are utilized. Even if your snowmobile is equipped with factory tunnel protection we suggest that you check for adequate clearance of traction products before you ride. Riding without performing a clearance check can result in serious damage to your snowmobile. Stud quantity and carbide length must be balanced for safe and proper handling. If you are not using studs do not install overly aggressive wearbars.