

STUD BOY APPLICATION CHART

SKI DOO 2010

Snowmobile Information			Riding Style				Wearbars		
			Safety		Performance				
2010 Model	Lug Height	Track Length	Stud Length	Stud Quantity	Stud Length	Stud Quantity	Deuce	Round	Shaper
MXZ X-RS 600	1.250	15 x 120	1.375	84	1.375	126	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
MXZ X-RS 800	1.250	15 x 120	1.375	126	1.375	168	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
MXZ Sport	1.000	15 x 120	1.080	84	1.080	126	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
MXZ Adrenaline 600 HO ETEC	1.000	15 x 120	1.080	84	1.080	126	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
800R Power TEK	1.000	15 x 120	1.080	126	1.080	168	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
MXZ TNT 550Fan	1.250	15 x 120	1.375	84	1.375	126	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
MXZ TNT 600 & 1200 4-TEC	1.000	15 x 120	1.080	84	1.080	126	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
MXZ X 600 HO ETEC /1200	1.250	15 x 120	1.375	84	1.375	126	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
MXZ X 800 Power TEK	1.250	15 x 120	1.375	126	1.375	168	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
Renegade Adrenaline 600 & 4-TEC	1.250	15 x 137	1.375	96	1.375	144	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
Renegade Sport 550Fan	1.250	15 x 137	1.375	144	1.375	192	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
Renegade BackCountry	1.250	15 x 137	1.375	96	1.375	144	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
Renegade BackCounty X	1.750	16 x 137	1.875	96	1.875	144	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
Renegade X 600 / 1200 4-TEC	1.750	16 x 137	1.875	96	1.875	144	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
Renegade X 800	1.250	15 x 137	1.375	96	1.375	144	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
Summit (ALL)	1.250	15 x 137	1.375	144	1.375	192	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
GSX Sport 600 & 550 Fan	2.250	16 x ALL	N/A	N/A	N/A	N/A	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
GSX LE 600 HO ETEC/4-TEC	1.000	15 x 120	1.080	84	1.080	126	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
GSX SE	1.000	15 x 120	1.080	84	1.080	126	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
Grand Touring Sport 600	1.000	15 x 137	1.080	96	1.080	144	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
Grand Touring Sport 550Fan	1.000	15 x 137	1.080	96	1.080	144	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
Grand Touring LE 600 HO	1.000	15 x 137	1.080	96	1.080	144	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
Grand Touring LE & SE 1200	1.000	15 x 137	1.080	96	1.080	144	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
Skandic Tundra	1.250	15 x 137	1.375	96	1.375	144	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
Skandic Tundra LT	1.500	16 x 154	1.625	62	1.625	124	DOO-D2410-(add size)	CAM-R2395-(add size)	CAM-S2395-(add size)
Skandic WT / SUV	1.250	20 x 156	1.375	93	1.375	124	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
Skandic SWT	1.250	24 x 156	1.375	93	1.375	124	N/A	N/A	N/A
Skandic Tundra Sport	1.250	16 x 137	1.375	96	1.375	144	N/A	N/A	N/A
Expedition (ALL)	1.250	20 x 156	1.375	93	1.375	124	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)

*120" Tracks Have 42 lugs/ 121" Tracks Have 48 Lugs /128" Tracks Have 51 Lugs/ 136" Tracks Have 54 Lugs / 141" Tracks Have 47 Lugs/144" Tracks Have 57 Lugs /156" Tracks Have 62 Lugs

**** PLEASE REMEMBER THAT "DEUCE" BARS ARE SOLD AS SINGLE BARS – NOT AS A PAIR**

Liberty Products, Inc. recommends that tunnel and/or heat exchanger protection be installed in all snowmobiles when traction products are utilized. Even if your snowmobile is equipped with factory tunnel protection we suggest that you check for adequate clearance of traction products before you ride. Riding without performing a clearance check can result in serious damage to your snowmobile. Stud quantity and carbide length must be balanced for safe and proper handling. If you are not using studs do not install overly aggressive wearbars.

******BOLDED ITEMS REPRESENT SINGLE PLY TRACKS AND REQUIRE POWER POINT +PLUS STUDS AND BACKERS**