

STUD BOY APPLICATION CHART

POLARIS 2010

Snowmobile Information			Riding Style				Wearbars		
			Safety		Performance				
2010 Model	Height	Length	Length	Quantity	Length	Quantity	Deuce	Round	Shaper
Trail Touring	1.000	15 x 136	1.080	108	1.080	108	NA	CAM-R2395-(add size)	CAM-S2395-(add size)
600 Rush	1.250	15 x 120	1.375	84	1.375	126	NA	CAM-R2395-(add size)	CAM-S2395-(add size)
Trail RMK	1.250	15 x 136	1.375	108	1.375	108	POL-D2370-(add size)	POL-R2370-(add size)	POL-S2370-(add size)
WideTrak IQ & 600 Wide	1.250	20 x 156	1.375	93	1.375	124	NA	NA	POL-S2484-(add size)
WideTrak LX	1.000	20 x 156	1.080	93	1.080	124	NA	NA	POL-S2484-(add size)
120 Dragon	0.790	10 x 69	N/A	N/A	N/A	N/A	NA	POL-R2219-(add size)	NA
550 IQ Shift	0.910	15 x 121	1.000	96	1.000	120	POL-D2370-(add size)	POL-R2370-(add size)	POL-S2370-(add size)
600 IQ	1.000	15 x 121	1.080	96	1.080	144	POL-D2370-(add size)	POL-R2370-(add size)	POL-S2370-(add size)
600 LX/Turbo LX	1.000	15 x 136	1.080	108	1.080	162	POL-D2370-(add size)	POL-R2370-(add size)	POL-S2370-(add size)
600 Switchback/Dragon SB	1.250	15 x 136	1.375	108	1.375	162	POL-D2370-(add size)	POL-R2370-(add size)	POL-S2370-(add size)
800 IQ	1.000	15 x 121	1.080	144	1.080	192	POL-D2370-(add size)	POL-R2370-(add size)	POL-S2370-(add size)
800 Dragon IQ	1.250	15 x 121	1.375	144	1.375	192	POL-D2370-(add size)	POL-R2370-(add size)	POL-S2370-(add size)
IQ Turbo Dragon	1.250	15 x 121	1.375	144	1.375	192	POL-D2370-(add size)	POL-R2370-(add size)	POL-S2370-(add size)
FST IQ Touring	1.000	15 x 136	1.080	108	1.080	162	POL-D2370-(add size)	POL-R2370-(add size)	POL-S2370-(add size)
600 IQ Touring	1.000	15 x 136	1.080	108	1.080	162	POL-D2370-(add size)	POL-R2370-(add size)	POL-S2370-(add size)
800 Switchback/Dragon SB	1.250	15 x 136	1.375	162	1.375	216	POL-D2370-(add size)	POL-R2370-(add size)	POL-S2370-(add size)
600 RMK's (ALL)	ALL	15 x ALL	N/A	N/A	N/A	N/A	NA	NA	POL-S2484-(add size)
800 RMK's (ALL)	ALL	15 x ALL	N/A	N/A	N/A	N/A	NA	NA	POL-S2484-(add size)

*121" Tracks Have 48 Lugs /128" Tracks Have 51 Lugs/ 136" Tracks Have 54 Lugs / 141" Tracks Have 47 Lugs/144" Tracks Have 57 Lugs /156" Tracks Have 62 Lugs

**** PLEASE REMEMBER THAT "DEUCE" BARS ARE SOLD AS SINGLE BARS – NOT AS A PAIR**

Liberty Products, Inc. recommends that tunnel and/or heat exchanger protection be installed in all snowmobiles when traction products are utilized.

Even if your snowmobile is equipped with factory tunnel protection we suggest that you check for adequate clearance of traction products before you ride. Riding without performing a clearance check can result in serious damage to your snowmobile. Stud quantity and carbide length must be balanced for safe and proper handling. If you are not using studs do not install overly aggressive wearbars.