

# STUD BOY APPLICATION CHART

## POLARIS 2011

Snowmobile Information			Riding Style				Wearbars		
			Safety		Performance		Deuce	Round	Shaper
2011 Model	Height	Length	Length	Quantity	Length	Quantity			
600 Rush Pro-R	1.250	15 x 121	1.375	120	1.375	168	POL-D2370-(add size)	POL-R2370-(add size)	POL-S2370-(add size)
800 Rush Pro-R	1.250	15 x 121	1.375	144	1.375	192	POL-D2370-(add size)	POL-R2370-(add size)	POL-S2370-(add size)
600 Rush	1.000	15 x 121	1.080	120	1.187	168	POL-D2370-(add size)	POL-R2370-(add size)	POL-S2370-(add size)
800 Rush	1.000	15 x 121	1.080	144	1.187	192	POL-D2370-(add size)	POL-R2370-(add size)	POL-S2370-(add size)
600 Rush LX	1.000	15 x 121	1.080	96	1.080	120	POL-D2370-(add size)	POL-R2370-(add size)	POL-S2370-(add size)
FS IQ WideTrak	1.250	20 x 156	1.375	93	1.375	124	N/A	N/A	POL-S2484-(add size)
600 IQ WideTrak	1.250	20 x 156	1.375	93	1.375	124	N/A	N/A	POL-S2484-(add size)
WideTrak LX	1.000	20 x 156	1.080	93	1.080	124	N/A	N/A	POL-S2484-(add size)
120 Assault	0.790	10 x 69	N/A	N/A	N/A	N/A	N/A	POL-R2219-(add size)	N/A
550 IQ Shift	0.910	15 x 121	1.000	96	1.000	120	POL-D2370-(add size)	POL-R2370-(add size)	POL-S2370-(add size)
550 Shift 136	1.250	15 x 136	1.375	96	1.375	120	POL-D2370-(add size)	POL-R2370-(add size)	POL-S2370-(add size)
550 IQ LXT	1.000	15 x 136	1.080	108	1.080	135	POL-D2370-(add size)	POL-R2370-(add size)	POL-S2370-(add size)
Turbo IQ LXT	1.000	15 x 136	1.080	108	1.080	135	POL-D2370-(add size)	POL-R2376-(add size)	POL-S2370-(add size)
600 IQ LXT	1.000	15 x 136	1.080	108	1.080	135	POL-D2370-(add size)	POL-R2376-(add size)	POL-S2370-(add size)
600 Switchback 136	1.250	15 x 136	1.375	108	1.375	162	POL-D2370-(add size)	POL-R2370-(add size)	POL-S2370-(add size)
600 Shift 136	1.250	15 x 136	1.375	108	1.375	162	POL-D2370-(add size)	POL-R2370-(add size)	POL-S2370-(add size)
Turbo IQ	1.250	15 x 121	1.375	96	1.375	144	POL-D2370-(add size)	POL-R2370-(add size)	POL-S2370-(add size)
Turbo IQ LX	1.000	15 x 136	1.080	108	1.080	135	POL-D2370-(add size)	POL-R2370-(add size)	POL-S2370-(add size)
600 IQ Shift	0.910	15 x 121	1.000	120	1.080	144	POL-D2370-(add size)	POL-R2370-(add size)	POL-S2370-(add size)
800 Switchback Assault 144	1.352	15 x 144	1.500	171	1.375	200	POL-D2370-(add size)	POL-R2370-(add size)	POL-S2370-(add size)
RMK's (ALL)	ALL	15 x ALL	N/A	N/A	N/A	N/A	N/A	N/A	POL-S2484-(add size)

\*121" Tracks Have 48 Lugs /128" Tracks Have 51 Lugs/ 136" Tracks Have 54 Lugs / 141" Tracks Have 47 Lugs/144" Tracks Have 57 Lugs /156" Tracks Have 62 Lugs

**\*\* PLEASE REMEMBER THAT "DEUCE" BARS ARE SOLD AS SINGLE BARS – NOT AS A PAIR**

Liberty Products, Inc. recommends that tunnel and/or heat exchanger protection be installed in all snowmobiles when traction products are utilized.

Even if your snowmobile is equipped with factory tunnel protection we suggest that you check for adequate clearance of traction products before you ride. Riding without performing a clearance check can result in serious damage to your snowmobile. Stud quantity and carbide length must be balanced

for safe and proper handling. If you are not using studs do not install overly aggressive wearbars.