

STUD BOY APPLICATION CHART

POLARIS 2013

Snowmobile Information			Riding Style				Wearbars		
			Safety		Performance				
2013 Model	Height	Length	Length	Quantity	Length	Quantity	Deuce	Round	Shaper
120 Pro-R	0.790	10 x 69	N/A	N/A	N/A	N/A	N/A	POL-R2219-(add size)	N/A
550 IQ LXT	1.000	15 x 136	1.080	108	1.080	135	POL-D2370-(add size)	POL-R2370-(add size)	POL-S2370-(add size)
550 IQ Shift	0.910	15 x 121	1.000	96	1.080	120	POL-D2370-(add size)	POL-R2370-(add size)	POL-S2370-(add size)
550 Shift 136	1.250	15 x 136	1.375	108	1.375	135	POL-D2370-(add size)	POL-R2370-(add size)	POL-S2370-(add size)
550 Shift 136 Canada	1.350	15 x 136	1.375	108	1.375	162	N/A	N/A	POL-S2484-(add size)
600 Indy	0.910	15 x 121	1.000	120	1.080	144	POL-D2370-(add size)	POL-R2370-(add size)	POL-S2370-(add size)
600 IQ LXT	1.000	15 x 136	1.080	108	1.080	135	POL-D2370-(add size)	POL-R2370-(add size)	POL-S2370-(add size)
600 IQ WideTrak	1.250	20 x 156	1.375	93	1.375	124	N/A	N/A	POL-S2484-(add size)
600 Rush / 600 Indy SP	1.000	15 x 121	1.080	120	1.187	144	POL-D2523-(add size)	POL-R2523-(add size)	POL-S2523-(add size)
600 Rush Pro-R	1.250	15 x 121	1.375	120	1.375	144	POL-D2523-(add size)	POL-R2523-(add size)	POL-S2523-(add size)
600 Switchback	1.250	15 x 136	1.375	108	1.375	162	POL-D2523-(add size)	POL-R2523-(add size)	POL-S2523-(add size)
600 Switchback Adventure	1.350	15 x 136	1.375	108	1.375	162	POL-D2523-(add size)	POL-R2523-(add size)	POL-S2523-(add size)
600 Switchback Pro-R	1.350	15 x 136	1.375	108	1.500	162	POL-D2523-(add size)	POL-R2523-(add size)	POL-S2523-(add size)
800 Rush	1.000	15 x 121	1.080	144	1.187	192	POL-D2523-(add size)	POL-R2523-(add size)	POL-S2523-(add size)
800 Rush Pro-R	1.250	15 x 121	1.375	144	1.375	192	POL-D2523-(add size)	POL-R2523-(add size)	POL-S2523-(add size)
800 Switchback	1.250	15 x 136	1.375	162	1.375	216	POL-D2523-(add size)	POL-R2523-(add size)	POL-S2523-(add size)
800 Switchback Assault 144	1.352	15 x 144	1.375	171	1.375	200	POL-D2370-(add size)	POL-R2370-(add size)	POL-S2370-(add size)
800 Switchback Pro-R	1.350	15 x 136	1.375	162	1.500	216	POL-D2523-(add size)	POL-R2523-(add size)	POL-S2523-(add size)
FS IQ WideTrak	1.250	20 x 156	1.375	93	1.375	124	N/A	N/A	POL-S2484-(add size)
RMK's (ALL)	ALL	15 x ALL	N/A	N/A	N/A	N/A	N/A	N/A	POL-S2484-(add size)
Turbo IQ LXT	1.000	15 x 136	1.080	108	1.080	135	POL-D2370-(add size)	POL-R2370-(add size)	POL-S2370-(add size)

*121" Tracks Have 48 Lugs /128" Tracks Have 51 Lugs/ 136" Tracks Have 54 Lugs / 141" Tracks Have 47 Lugs/144" Tracks Have 57 Lugs /156" Tracks Have 62 Lugs

Round bars -40 = 4", -60 = 6", -90 = 9" - Deuce Bars -45 = 4.5", -60 = 6", -90 = 9" - Shaper Bars -45 = 4.5", -60 = 6", -75 = 7.5", -90 = 9"

**** PLEASE REMEMBER THAT "DEUCE" BARS ARE SOLD AS SINGLE BARS – NOT AS A PAIR**

Liberty Products, Inc. recommends that tunnel and/or heat exchanger protection be installed in all snowmobiles when traction products are utilized.

Even if your snowmobile is equipped with factory tunnel protection we suggest that you check for adequate clearance of traction products before you ride. Riding without performing a clearance check can result in serious damage to your snowmobile. Stud quantity and carbide length must be balanced for safe and proper handling. If you are not using studs do not install overly aggressive wearbars.