

STUD BOY APPLICATION CHART

SKI DOO 2014

Snowmobile Information			Riding Style				Wearbars		
			Safety		Performance				
2014 Model	Lug Height	Track Length	Stud Length	Stud Quantity	Stud Length	Stud Quantity	Deuce	Round	Shaper
Expedition SE / LE 600HO / 1200	1.250	20 x 154	1.375	108	1.375	162	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
Expedition Sport 550F / 600 ACE / 900 ACE	1.500	16 x 154	1.625	108	1.625	162	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
Freeride 137	2.250	16 x 137	N/A	N/A	N/A	N/A	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
Freeride 146/154	2.500	16x 146 or 154	N/A	N/A	N/A	N/A	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
Grand Touring Sport 550 Fan / 600	1.250	16 x 137	1.375	96	1.375	144	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
Grand Touring Sport 600 ACE	1.000	15 x 137	1.080	96	1.080	144	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
Grand Touring LE 900 ACE	1.000	15 x 137	1.080	96	1.080	144	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
Grand Touring SE/ LE 600 HO / LE 1200	1.000	15 x 137	1.080	96	1.080	144	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
GSX LE 600HO / 900ACE / 1200	1.250	15 x 120	1.375	84	1.375	126	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
GSX SE 600 HO / 800R / 1200	1.250	15 x 137	1.375	144	1.375	192	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
MXZ Sport 550F/ 600	1.250	15 x 120	1.080	84	1.080	84	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
MXZ Sport 600 ACE	1.000	15 x 120	1.375	84	1.375	126	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
MXZ TNT 600 HO / 800R / 900ACE / 1200	1.250	15 x 120	1.375	126	1.375	168	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
MXZ X-RS 600 HO / 800 R	1.250	15 x 120	1.375	126	1.375	168	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
MXZ X 600HO / 800R / 1200	1.250	15 x 120	1.375	84	1.375	126	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
Renegade Adrenaline 600 / 1200	1.250	16 x 137	1.375	144	1.375	192	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
Renegade Adrenaline 800 R / 900 ACE	1.250	16 x 137	1.375	144	1.375	192	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
Renegade BackCountry 600 / 800 R	1.750	16 x 137	CALL	96	CALL	144	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
Renegade BackCountry X 600 / 800R	1.750	16 x 137	CALL	96	CALL	144	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
Renegade Sport 550 Fan / 600 ACE	1.250	15 x 137	1.375	96	1.375	144	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
Renegade X 600 / 800 R / 1200	1.250	16 x 137	1.375	144	1.375	192	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
Skandic WT 550F / 600 ACE / 600 HO	1.500	20 x 154	1.625	108	1.625	162	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
Skandic SWT 600HO / ACE 600	1.250	24 X 156	NA	NA	NA	NA	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
Summit SP / X	2.500	16 X 146 or 154 or 163	N/A	N/A	N/A	N/A	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
Summit Sport	2.250	16 X 146 or 154	N/A	N/A	N/A	N/A	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
Tundra LT 550F / 600 ACE	1.500	16 x 154	1.625	62	1.625	122	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
Tundra Sport 550F / 600 ACE	1.250	16 x 137	1.375	144	1.375	192	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
Tundra Xtreme	2.250	16 x 154	N/A	N/A	N/A	N/A	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)

Tracks Have 54 Lugs / 141” Tracks Have 47 Lugs/144” Tracks Have 57 Lugs /156” Tracks Have 62 Lugs

Round bars -45 = 4.5", -60 = 6", -75 = 7.5" - Deuce Bars -45 = 4.5", -60 = 6", -90 = 9" - Shaper Bars -45 = 4.5", -60 = 6", -75 = 7.5", -90 = 9"

AT “DEUCE” BARS ARE SOLD AS SINGLE BARS – NOT AS A PAIR

per protection be installed in all snowmobiles when traction products are utilized. Even if your snowmobile is for adequate clearance of traction products before you ride. Riding without performing a clearance check can antity and carbide length must be balanced for safe and proper handling of your aggressively aggressive wearbars.

TRACK AND STUD INFORMATION IN BOLD REPRESENT SINGLE PLY TRACKS WHICH REQUIRE POWER POINT PLUS STUDS