



# STUD BOY APPLICATION CHART

## SKI DOO 2015



Snowmobile Information			Riding Style				Wearbars		
			Safety		Performance				
2015 Model	Lug Height	Track Length	Stud Length	Stud Quantity	Stud Length	Stud Quantity	Deuce	Round	Shaper
Expedition SE / LE 600 HO 900 ACE 1200	<b>1.250</b>	<b>20 x 154</b>	<b>1.375</b>	<b>108</b>	<b>1.375</b>	<b>162</b>	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
Expedition Sport 550F / 600 ACE / 900 ACE	<b>1.500</b>	<b>16 x 154</b>	<b>1.625</b>	<b>108</b>	<b>1.625</b>	<b>162</b>	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
Freeride 137	1.750 or 2.25	16 x 137	CALL	N/A	CALL	N/A	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
Freeride 146/154	2.500	16x 146 or 154	N/A	N/A	N/A	N/A	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
Grand Touring Sport 550 Fan / 600 ACE	<b>1.250</b>	<b>16 x 137</b>	<b>1.375</b>	<b>96</b>	<b>1.375</b>	<b>144</b>	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
Grand Touring SE / 600 HO 900ACE 1200 LE	<b>1.000</b>	<b>15 x 137</b>	<b>1.080</b>	<b>96</b>	<b>1.080</b>	<b>144</b>	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
GSX LE 600HO / 900ACE / 1200	<b>1.250</b>	<b>15 x 120</b>	<b>1.375</b>	<b>84</b>	<b>1.375</b>	<b>126</b>	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
GSX SE 600 HO / 800R / 1200	<b>1.250</b>	<b>15 x 137</b>	<b>1.375</b>	<b>96</b>	<b>1.375</b>	<b>144</b>	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
MXZ Sport 600 Carb / 600 ACE	<b>1.250</b>	<b>15 x 120</b>	<b>1.080</b>	<b>84</b>	<b>1.080</b>	<b>84</b>	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
MXZ TNT 600 HO / 800R / 900ACE / 1200	<b>1.250</b>	<b>15 x 120</b>	<b>1.375</b>	<b>126</b>	<b>1.375</b>	<b>168</b>	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
MXZ X-RS 600 HO / 800 R	<b>1.250</b>	<b>15 x 120</b>	<b>1.375</b>	<b>126</b>	<b>1.375</b>	<b>168</b>	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
MXZ X 600HO / 800R / 1200	<b>1.250</b>	<b>15 x 120</b>	<b>1.375</b>	<b>84</b>	<b>1.375</b>	<b>126</b>	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
Renegade Adrenaline 600 / 1200	<b>1.250</b>	<b>15 X 137</b>	<b>1.375</b>	<b>144</b>	<b>1.375</b>	<b>144</b>	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
Renegade Adrenaline 800 R / 900 ACE	<b>1.250</b>	<b>15 X 137</b>	<b>1.375</b>	<b>144</b>	<b>1.375</b>	<b>144</b>	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
Renegade BackCountry 600 / 800 R	<b>1.750</b>	<b>16 x 137</b>	<b>CALL</b>	<b>96</b>	<b>CALL</b>	<b>144</b>	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
Renegade BackCountry X 800R	<b>1.750</b>	<b>16 x 137</b>	<b>CALL</b>	<b>96</b>	<b>CALL</b>	<b>144</b>	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
Renegade Sport 600 Carb / 600 ACE	<b>1.250</b>	<b>15 x 137</b>	<b>1.375</b>	<b>96</b>	<b>1.375</b>	<b>144</b>	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
Renegade X 600 / 800 R / 1200	<b>1.250</b>	<b>15 X 137</b>	<b>1.375</b>	<b>144</b>	<b>1.375</b>	<b>144</b>	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
Renegade X-RS 800 R	<b>1.250</b> or <b>1.50</b>	<b>15 x 137</b>	<b>1.375/1.625</b>	<b>144</b>	<b>1.375/1.625</b>	<b>144</b>	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
Skandic WT 550F / 600 HO / 600 & 900 ACE	<b>1.500</b>	<b>20 x 154</b>	<b>1.625</b>	<b>108</b>	<b>1.625</b>	<b>162</b>	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
Skandic SWT 600 HO / 900 ACE	<b>1.250</b>	<b>24 X 156</b>	<b>NA</b>	<b>NA</b>	<b>NA</b>	<b>NA</b>	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
Summit SP / X	2.500	16 X 146 or 154 or 163	N/A	N/A	N/A	N/A	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
Summit Sport	2.250	16 X 146 or 154	N/A	N/A	N/A	N/A	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
Summit X with T3 package	3.000	16x 163 or 174	N/A	N/A	N/A	N/A	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
Tundra LT 550F / 600 ACE	<b>1.500</b>	<b>16 x 154</b>	<b>1.625</b>	<b>62</b>	<b>1.625</b>	<b>122</b>	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
Tundra Sport 550F / 600 ACE	<b>1.250</b>	<b>16 x 137</b>	<b>1.375</b>	<b>96</b>	<b>1.375</b>	<b>144</b>	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)
Tundra Xtreme 600 HO	2.250	16 x 154	N/A	N/A	N/A	N/A	DOO-D2410-(add size)	DOO-R2410-(add size)	DOO-S2410-(add size)

Tracks Have 54 Lugs / 141" Tracks Have 47 Lugs/144" Tracks Have 57 Lugs /156" Tracks Have 62 Lugs

Round bars -45 = 4.5", -60 = 6", -75 = 7.5" - Deuce Bars -45 = 4.5", -60 = 6", -90 = 9" - Shaper Bars -45 = 4.5", -60 = 6", -75 = 7.5", -90 = 9"

### AT "DEUCE" BARS ARE SOLD AS SINGLE BARS – NOT AS A PAIR

For protection be installed in all snowmobiles when traction products are utilized. Even if your snowmobile is not equipped with adequate clearance of traction products before you ride. Riding without performing a clearance check can result in damage to your snowmobile and carbide length must be balanced for safe and proper handling of more aggressively aggressive wearbars.

**TRACK AND STUD INFORMATION IN BOLD REPRESENT SINGLE PLY TRACKS WHICH REQUIRE POWER POINT PLUS STUDS**